




5 Troubleshooting

- Notes:
- Before troubleshooting, setup the PC's display as below.
 - Resolution: 1024 x 768
 - H-frequency: 61 kHz
 - V-frequency: 75 Hz
 - If no picture appears, make sure the power cord is correctly connected.
 - Check the following circuits.
 - No raster appears: Function PBA, Main PBA, I/D PBA
 - 5V develop but no screen: Main PBA
 - 5V does not develop: I/D PBA
 - If you push and hold the " (Enter, Source)" button for more than 5 seconds, the monitor automatically returns to the factory preset.


5-1-1 No Power (MJ15A*/MJ15B*)



* 0V means power on state.
When the monitor work well except DPMS and power
switch off,
0V should be applied to number 4 of CN600.


- Notes:
- Before troubleshooting, setup the PC's display as below.
 - Resolution: 1280 x 1024
 - H-frequency: 64 kHz
 - V-frequency: 60 Hz
 - If no picture appears, make sure the power cord is correctly connected.
 - Check the following circuits.
 - No raster appears: Function PBA, Main PBA, I/P PBA
 - 5V develop but no screen: Main PBA
 - 5V does not develop: I/P PBA
 - If you push and hold the “ (Enter/Source)” button for more than 5 seconds, the monitor automatically returns to the factory preset.

5-1-2 No Power (MJ17A*/MJ19A*/MJ17B*/MJ19B*/MJ19E*)






* 0V means power on state.
When the monitor work well except DPMS and power
switch off,
0V should be applied to number 4 of CN600.


5-2-1 No Video (ANALOG)



WAVEFORMS



5-2-2 No Video (DIGITAL)



WAVEFORMS

